

Body Shield

Rocker

Body shield is a textured material with permanent adhesive. It can be removed safely from stable finishes. It can be used to cover surface imperfections to help conceal them. It should be installed above 50° F. Best installations are done in closer to room temperature. If done in excessive heat it may adhere to quickly for dry installations. In colder environments it may not conform as well. Make sure the surface is clean to be sure of good adhesion to the vehicle. In some application it may be installed by misting the adhesive backing with an mixture of soap and water. This solution is made by adding 4-5 large drops of baby shampoo to 32oz. Of water in a spray bottle. Other applications it will be installed dry. When placing the material on the car do not press it down hard till you are satisfied with the location. You can pull it off to reposition as long as you install it without too much pressure. Once the material is in position you can then press it firmly down to the surface. In the event of the wet installation a hair dryer can speed up drying but it must be firmly in place before driving. Locate the parts for each section, if multiple pieces are in the product being installed before starting, making sure to know were each piece goes. Reading the instructions through and studying the photos will help with this.

Tools Required:

X-acto knife

Spray bottle with dish soap & water mixture

Surface cleaner– such as Mequians Deep Crystal System paint cleaner

JK Rockers

Step 1:

Clean surface you are applying the material to. You may use a commercially available cleaner designed for auto finishes. When it is time to spray the material peel backing from material exposing the adhesive. Spray material with a light amount of the soap and water mixture. Simply mist the material This will help the adhesive from not sticking right away till you get it in place.



Step 2:

On material for the rocker area remove the body piece and spray the material as described before. Place it on the vehicle. Evenly space the vinyl on the door seams and the front and rear fender area. Then add the door pieces. Spray and align the door pieces so they are space at the door gap like the body panels were. Also make sure that the top is level between the door and body panels. You may use a hair dryer to dry the material. Remember wait ample time to make sure it is dry before driving



TJ Rockers

Step 1: Remove the bolts securing the flare extension and remove it. Next remove the 3 bottom bolts securing the fender flares. This will give you access to place the material under the flare.

Step 2: Clean surface you are applying the material to. You may use a commercially available cleaner designed for auto finishes. When it is time to spray the material peel backing from material exposing the adhesive. Spray material with a light amount of the soap and water mixture. Simply mist the material This will help the adhesive from not sticking right away till you get it in place.

Step 3: place the material on the vehicle. On this product there is one hole in it to place over the bottom fender flare mounting bolt hole under the front and rear fender flares. Align the material to run level along the vehicle and use the bottom as a guide when aligning the material. Tucking the material under the fender flares.

Step 4: Remount the fender flares. Also remount if desired the flare extensions. The material is not cut for those mounting hole in case these are not present on your vehicle or you choose to not reinstall them. In the case that you would like them back on. Simply use an x-acto knife and poke through the center of the hole then with the tip of the blade in the hole using it as a guide cut in a circular motion to remove material for bolt clearance.



After installation you would do best by leaving ample dry time before driving or washing the vehicle, if you installed the recommended wet method. This is a permanent adhesive on this product. Great care should be taken if it is needed to be removed later.