



*****Before beginning, be sure the grille area is clean and free of any grease, dirt, or dust*****

Step 1:

Using the supplied alcohol prep pads, thoroughly wipe down the area of the grille where the 3M tape from the grille cover will adhere.



Step 2:

Peel the backing from the 3M tape on the grille cover and install over the factory grille as shown. Start by lining up the lower part of the cover with the grille openings, then tilt the cover towards the top of the grille.



Installation Instructions for Barricade Matte Black Grille Cover (97-06 Wrangler TJ)

J100722 – Matte Black

Step 3:

Once the cover is positioned properly over the grille, press down firmly to fully seat the adhesive tape.

