

Installation Instructions for Barricade Adventure Mirrors

Part Numbers: J100723/J100724

Tools Required:

13mm & 15mm Wrenches or Sockets

Step 1:

Remove the door from your Jeep by supporting the weight and pulling up and releasing the pins as shown. Be sure to have somewhere to put the door when removed.



Step 2:

Installed the threaded end of the mirror support through the top door pin hole and secure using the supplied lock washer and nut. Use a 15mm wrench or socket to tighten the nut.



Step 3:

Once the support rod is secured to the upper door pin mounting hole, install the mirror assembly using the included 13mm bolt as shown.



Step 4:

Repeat Steps 1-3 for opposite side mirror. Once both mirrors are securely mounted, be sure to adjust them before driving the vehicle.