



LOCKING FUEL DOOR

(2007-2018 Wrangler JK)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Fuel Door
- (4) Phillips Head Screws
- (2) Keys

TOOLS REQUIRED

- Phillips Head Screwdriver
- 7/64" Drill Bit
- Drill

STEP 1

Remove the factory fuel cap from the vehicle, this will allow for some extra room during installation. Position the locking fuel door over the plastic trim ring as shown. Once centered, use the supplied self tapping screws to make four marks for drilling.

STEP 2

Remove the door from the vehicle and drill the four marked spots with a 7/64 bit as shown.



STEP 3

Use the four supplied self tapping screws to secure the locking fuel door to the factory plastic trim ring. Do not overtighten. Once the new fuel door is secured, reinstall the fuel cap removed in Step 1. This completes the installation of your new Barricade Locking Fuel Door.