Installation Instructions for Red Rock 4x4 Angry Eyes (97-06 Wrangler TJ)

Tools Required: T15 Torx Screwdriver or Bit

Step 1:

Remove the three Torx screws securing the factory headlight bezel and remove it from the vehicle.



Step 2:

Place the Angry Eyes Bezel in place of the factory bezel and secure using the three screws removed in Step 1.







Step 3:

Repeat Steps 1-2 for opposite side bezel to complete the installation.

