

Barricade Enhanced Rubi Rails

Installation Time: 1 Hour

Tools Required:

- ✓ 3/8" Drill Bit
- ✓ 13MM Socket
- ✓ 10MM Socket
- ✓ 10MM Wrench

Notes: Middle mounting location on rail is offset to the front of the rail, use this to determine which the passenger or driver side is

Installation Instructions:

1. Bore out the pinchweld mounting location to avoid fouling threads on studs of rail.



2. Insert threaded metal clip holes on underside of body. On 2015 JKU these clips may not be needed, as there is a threaded hole in place.



3. Seat rail into position.



4. Install flat washer and 10mm locknut onto studs. Rear passenger side may be too close to body mount location for a socket and ratchet, if this is the case use a wrench to install.
5. Install flat washer, lock washer, and 13mm bolt into threaded hole.



6. Tighten all nuts and bolts.

Before



After



Installation Instructions Written by ExtremeTerrain Customer John Hankins 12/19/2015