

## **Barricade Turn Signal Guard Instructions**

**Installation Time:** 10 Minutes

**Tools Required:**

- ✓ Alcohol Pad (supplied)
- ✓ Utility Knife



**Installation Instructions:**

1. Thoroughly clean the surface of the side marker with the alcohol pad (Pic 1)



**(Pic 1)**

2. Allow the side marker to dry. (Pic 2)



**Pic 2**

3. Remove the 3M tape backing (Pic 3)



**Pic 3**

4. Align the guard over the marker and press firmly. Be sure to press evenly to seat the guard. (Pic 4)



**Pic 4**

5. Finished



**PIC 5**