

Surco Hardtop Carrier

Installation Guide for Jeep Wrangler 2-Door JK

Installation Time: Less Than One Hour

Tools Required:

- ✓ Box Cutter or Knife for Packaging
- ✓ Crescent Wrench

Ensure that all pieces and hardware are included before beginning installation.

Installation Instructions:

1. Using a box cutter, carefully open the cardboard box along the corners.
2. Once the box is open (Figure A), make sure all pieces and hardware are present. You should have three separate pieces and a box that contains four casters and the adjoining four lock washers and four acorn nuts.



Figure A

3. Remove the packaging carefully with the box cutter, being certain not to cut into the finish on the pieces (Figure B).



Figure B

4. Once removed, align your pieces in the appropriate order (Figure C).



Figure C

5. When aligning the pieces, ensure that the bracket pieces are facing upward to choose which side affixes to the left and right (Figure D).



Figure D

6. Line up holes shown in Figure E according to your vehicle year (align outside holes for Wranglers 67-06; inside holes for JK 07-16).



Figure E

7. Align and insert all four casters (Figure F).



Figure F

8. Attach the lock washer and acorn nut on each caster (Figure G).



Figure G

9. The locking casters affix to the front end (Figure H); non-locking casters to the back end.



Figure H

10. Tighten each lock washer and acorn nut with a crescent wrench (Figure I).



Figure I



Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 03/16/2017