



# INSTALLATION INSTRUCTIONS

07-14 Jeep Wrangler JK  
Part Number: J101069



## INCLUDED COMPONENTS:

2 Fenders  
16 13mm Nuts  
16 14mm Bolts  
16 Washers

## TOOLS REQUIRED:

Phillips Screwdriver  
13mm, 14mm & 10mm Socket Wrench

**Please read and understand all instructions before starting the installation. The manufacturer is in no way responsible for any personal injury or vehicle damage that may occur during the installation or use of this product.**  
**CAUTION: This product is designed primarily to enhance the appearance of this vehicle. Do not rely on it in any way to protect against injury or death in the event of an accident.**

1. Remove the OE Signal Light by twisting off the connector and begin to unclip the wire (you will not be needing the Signal Light) shown in Fig 1.
2. There will be (4) 10mm Bolts underneath the front OE fender, with a 10mm Socket Wrench, begin to remove these (4) 10mm Bolts shown in Fig 2.
3. Once you remove the (4) 10mm Bolts on the front OE fender there will be (2) more 10mm Bolts in the rear that you will need to remove shown in Fig 3.
4. Begin to pull away the OE fender with some pressure shown in Fig 4.
5. Begin to put the new Fender and Place in the 14mm Bolts, Washers and Nuts shown in Fig 5 (you will need a 13mm and 14mm Socket Wrench to thread in the Bolt and Nut together). Repeat this for the other side of the Fender.
6. Congratulations on your finished Installation. Enjoy

