



INCLUDED COMPONENTS:

- 2 Fenders
- 16 13mm Nuts
- 16 14mm Bolts
- 16 Washers

TOOLS REQUIRED:

- Phillips Screwdriver
- 13mm & 14mm Socket Wrench
- Pick & Hook Set
- Flat Screwdriver

Please read and understand all instructions before starting the installation. The manufacturer is in no way responsible for any personal injury or vehicle damage that may occur during the installation or use of this product.
CAUTION: This product is designed primarily to enhance the appearance of this vehicle. Do not rely on it in any way to protect against injury or death in the event of an accident.

1. Along the side fender wall there will be push in clips that you will need to remove either with a thin Phillips Screwdriver or a Pick & Hook Set shown in Fig 1.
2. After you remove the push in clips begin to remove (2) Push in Clips with a push clip remover or flat screwdriver shown in Fig 2.
3. On the inner Fender Wall there will be (2) Push Clips behind the Tire, remove these (2) Clips with a push clip remover or flat screwdriver as well shown in Fig 3.
4. Begin to pull away the OE fender with some pressure shown in Fig 4.
5. Begin to put the new Fender and Place in the 14mm Bolts, Washers and Nuts shown in Fig 5 (you will need a 13mm and 14mm Socket Wrench to thread in the Bolt and Nut together). Repeat this for the other side of the Fender.
6. Congratulations on your finished Installation. Enjoy

