

## Installation Guide for Barricade FullShade Top (07-15 Wrangler JK 4 Door) Item # J101173

**Installation Time:** 30 Minutes

**Tools Required:**

- ✓ Hands!

*This installation was performed on a 2014 Unlimited Sport.*

**Installation Instructions:**

1. Remove the soft top or hard top and open all doors.



2. Start by unfolding the shade and spreading it across the top of the jeep. The pockets go towards the front with the zippers facing down.



3. First connect the middle clip to the footman loop above the rearview mirror.



4. Next move to the rear of the vehicle and use the two straps to cinch down the last hole on the passenger and driver sides.







5. Move back up to the front and start using the bungee cords to install the first hole on the driver and passenger side. Work the bungee cord under the plastic trim piece. Rotate the ball up under the shade for a clean look.



6. Move from the front of the vehicle to the rear alternating sides as you secure the top with the bungee cords. You can align the holes on the shade as you work your way down.



7. Once you have secured both sides with the bungee cords, you're done! Now go enjoy your new shade.



## Before and After:



### *Final Notes:*

- Make sure the holes align in the middle or you might not be able to install your top on over the shade.
- No more sunburn!

Installation Instructions Written by ExtremeTerrain Customer Erik Shrunk 8/16/2015