



## ONE PIECE WRAPAROUND NET

### YJ/ TJ WRANGLER '92-'06

1. Lay the net out on a flat surface with the label facing up and at the right side.
2. The label will face out on the right side of the Jeep when installed.
3. Loosely connect the upper most webbing with connector around the roll bar on the passenger side just above the seat belt bolt.
4. Do the same with upper most strap on the drivers side.
5. Connect the balance of the straps.
6. Adjust as necessary for proper alignment of the vertical and horizontal straps.
7. Conceal the strap ends by pushing them back through the plastic connectors and rolling them up.

**Note:** Steel roll bar cages are subject to expansion and contraction with temperature variations. Occasional tightening of the net may be needed at first and best done in the morning when cool.

**Tip:** To pull straps extra tight, grip with a pair of pliers when tightening.

