



BARRIER/DOG NET '92-'06 JEEP

1. Lay the net on a flat surface with the label at the top right.
2. The label will be facing the back seat area from the passenger side.
3. From the back seat, attach the top connectors with the strap a few inches above the seat belt bolt housing and around the roll bar.
4. Attach the lower connectors to the roll bar at about the same level as the seat back release levers.
5. Adjust as needed.

Note: Roll bar cages will expand and contract with temperature changes. Occasional tightening of the net will be needed at first and best done in the morning when it is cool.

Tip: To get the straps extra tight, use pliers to grip the strap ends.

