



### '04-'06 LJ FRONT OVERHEAD NET

1. Lay net out on a flat surface with the label at the top right.
2. The label will be facing up on the passenger side at the windshield.
3. Attach the front center strap to the footman loop on the center of the windshield as tightly as possible.
4. Attach the rear center strap around the sound bar as tightly as possible.
5. Attach the side straps around the roll bar, making adjustments to keep the center strap straight.

**Note:** Roll cages and nylon webbing will expand and contract with temperature changes. Occasional morning tightening may be necessary.

**Tip:** Gripping the strap ends with pliers will give more tightening ability.

