



2007- PRESENT JK 2 DOOR

Lay the net out onto a large flat surface with the label at the top right. The label will face out on the right hand side of the Jeep when installed.

Attach the upper right hand strap around the roll bar to the connector buckle just above the seat belt bolt on the passenger side of the Jeep and the same on the driver's side. Pull slightly tight.

Working downward, connect the other straps to the connectors leaving the lowest one somewhat loose. Attach the cross piece connectors at the rear corners (see photo).

Tighten and adjust as needed.

To conceal the strap ends, slip them back through the slot in the plastic connector and roll up.

Note: Roll bar cages will expand and contract with temperature changes and the net will need tightening the 1st couple of days and best done in the morning.

Tip: To get the net extra tight, grab the strap ends with a pair of pliers when pulling.

