



FRONT OVERHEAD NET 2007-PRESENT 2 DOOR WRANGLER

1. Lay the net out on a flat surface with the label at the top right.
2. Attach all 3 front straps to the footman loops above the windshield.
3. Attach the rear straps around the roll bar.
4. Attach the 8 side straps and the 2 corner straps to the roll bar.
5. Adjust as necessary.
6. The excess straps may now be cut off or tucked back inside the connectors and rolled up.

Note: Metal roll cages will expand and contract with temperature changes. Occasional tightening of the straps may be needed the first few days and best done in the morning when it is cool.

Tip: Grabbing the nylon webbing end with a pair of pliers will help get a better grip to pull it tighter.

