



**REAR OVERHEAD NET
2 DOOR JK
2007 TO PRESENT**

Lay the net out onto a flat surface with the label at the top right. When the net is installed, the label will be facing up on the right hand side of the Jeep.

Attach the straps around the roll bar and back to the plastic connectors (see photo). Adjust as needed.

When used with the one piece wraparound net, the lowest horizontal strap of the overhead net should align with the upper most horizontal strap of the wraparound net.

To conceal the strap ends, feed them back through the slot in the plastic connector and roll up.

Note: Roll bar cages will expand and contract with temperature variations and the net will need to be tightened for the 1st couple of days and best done in the morning.

Tip: To get the net extra tight, pull the strap ends while gripping them with a pair of pliers.

