



FRONT BARRIER NET

4 DOOR JK 2007 TO PRESENT

1. Lay the net out on a flat surface with the label facing up & at the top right. This will be facing the cargo/passenger area when installed.
2. Move the front seats all the way forward.
3. Place the 2 metal cargo hooks under the steel seat mounts as shown in photo.
4. Place the straps around the roll/sound bar in the location shown in the photo.
5. Connect the straps to the plastic connectors and tighten.

Note: Nylon webbing will stretch somewhat at first and may need occasional tightening. This is best done in the morning when it is cool.

Tip: When tightening the straps, grab a hold of the ends with pliers for extra pulling leverage.

This net will include a strap with a buckle alongside the strap with the hook. Some later model JK Wranglers have different seat supports and where the hooks won't work, simply use the strap to go around the seat support and back to the buckle. Whichever one is not used can be cut off and discarded.

