



## REAR BARRIER NET

### JEEP JK 4 DOOR 2007-PRESENT

1. Lay the net out on a flat surface with the label facing up and toward you. The label will face the cargo area when installed.
2. Run the long connecting straps over the roll bar on each side and connect at the overhead interior light. Leave enough slack to be able to connect the lower straps.
3. The lower corners are attached to the metal Jeep body with the “cargo hooks.” Push the hooks into place between the fabric sidewall of the cargo area and the lower edge of the Jeep body. You will find the metal curls down forming a “lip.” When in place, tighten the upper strap.
4. Adjust as needed and attach the 4 “hook & loop” fabric fasteners around the roll bar tight enough to prevent flapping, but not so tight as to distort the shape of the net.

Note - Metal roll cages expand and contract with temperature changes. Occasional tightening may be needed the 1<sup>st</sup> few days and best done in the morning when it is cool.

