



**REAR OVERHEAD NET
2007 TO PRESENT
4 DOOR JK**

1. Lay the net on a flat surface with the label at the top right. The label will be facing up and just behind the front passenger seat when installed.
2. Connect the long front straps around the front roll bar.
3. Take the other end of those two straps and attach around the rear roll bar.
4. Connect all eight side straps.
5. Adjust as needed.
6. The excess strap ends may now be cut off or pushed back through the connector and rolled up out of sight.

Note: Metal roll cages will expand and contract with temperature changes. Occasional tightening may be needed the first few days and best done in the morning when it is cool.

Tip: Grabbing a hold of the nylon ends with a pair of pliers will give better leverage to pull the straps tighter.

