

Installation Instructions for MONSTER HOOK SWIVELS

Installation Time: 15 Minutes

Tools Required:

- ✓ Ring Expander Pliers



Installation Instructions:

1. Unpackage your new Monster Hook Swivels and find your metal “o” rings



2. Before installing your new swivels remove any pre-existing d-rings. Then place 1 of the metal "o" rings to one end of the pin.



3. Place Monster Hook Swivel on bumper and slide pin in place.



4. Use your pliers and attach remaining "o" ring. Once on the pliers, expand and slide on the remaining side.





Installation Instructions Written by ExtremeTerrain Customer JeepModReview 08/18/2016