

## Installation Instructions for Barricade Adventure Mirrors

**Part Numbers:** J100723/J100724

### **Tools Required:**

13mm & 15mm Wrenches or Sockets

### **Step 1:**

Remove the door from your Jeep by supporting the weight and pulling up and releasing the pins as shown. Be sure to have somewhere to put the door when removed.



### **Step 2:**

Installed the threaded end of the mirror support through the top door pin hole and secure using the supplied lock washer and nut. Use a 15mm wrench or socket to tighten the nut.



### **Step 3:**

Once the support rod is secured to the upper door pin mounting hole, install the mirror assembly using the included 13mm bolt as shown.



### **Step 4:**

Repeat Steps 1-3 for opposite side mirror. Once both mirrors are securely mounted, be sure to adjust them before driving the vehicle.