

## Installation Instructions for Recon Smoked Side Marker Lights with Amber LEDs

**Installation Time:** 1 Hour

**Tools Required:**

- ✓ Needle Nose Pliers
- ✓ Wire Cutter
- ✓ 4 Butt Wire Connectors
- ✓ Electrical Tap (optional)

**Installation Instructions:**

1. Twist and disconnect the factory wiring from the stock side marker.



2. Remove factory light by removing fender plug and sliding out. This will take some maneuvering to fully remove.



3. Before installing new Recon lights, strip wires and attach one end of the butt connectors.



4. Next, carefully slide new Recon lights into place and ensure clips are in place and wires are not damaged. Once in place, remove factory connector, strip the wires and and connect to the opposite ends of the butt connectors attached to the Recon lights you put in place.



5. Lastly, turn on your lights/blinders to test the connections. Lights should come on and look like this:

