

## Installation of Raxiom Headlight LED Conversion Bulb Kit (Jeep TJ 97-06)

**Installation Time:** 30 Minutes

**Tools Required:**

- #15 size Torx head screw driver

Before:



**Installation Instructions:**

- Remove the three screws holding the headlight bezel in place.



- Remove the four screws holding the headlight retaining bracket.



- Open the two metal pins and remove the bulb.



- Insert the LED bulb and close the pins.



- Run wires through the grill and into the Jeep and plug in.



Installation Instructions Written by ExtremeTerrain Customer Josh Hughes 02/04/2016