



Installation Instructions for Raxiom Replacement LED Fog Lights JK

Tools Needed:

- Flat Screw Driver
- Phillips Screw Driver
- Wire Stippers

**NOTE:

Removal of bumper is not necessary but can make the job easier.

Step 1:

Remove the 6 pins holding the splash guard onto the vehicle



Step 3:

To remove the fog lights, loosen the 4 phillips screws on each light.



Step 2:

Next, unplug the factory fog lights and loosen the (8) 19mm nuts holding the front bumper to the support beam of the vehicle.



Step 4:

Wire LED Pigtail. Blue wire to factory black wire. Brown Wire to the factory White or white and red wire.

Step 5:

Follow steps 1-3 in reverse.

