

Installation Instructions

Barricade Extreme HD Rocker Steps (07 – 16 Wrangler JK 2-Door)

Installation Time: Approximately 30 – 60 minutes

Tools Required:

- ✓ Socket Wrench
- ✓ 16MM or $\frac{5}{8}$ Deep-Well Socket
- ✓ Thread lock



Installation Notes: The factory hardware will be used to mount the Steps.

Installation Instructions:

1. Locate the body mount brackets on the side of the frame. (fig.1)

2. Remove the two 16MM nuts on either side of the Bushing Bolt, on both the forward and rear brackets. (fig.2)



FIG. 1



FIG. 2

3. Apply thread lock to the studs.
4. Lift the Step into position. Place the tongue of the Step mount over the Bushing Bolt washer and onto the studs. (fig.3&4)
5. Loosely thread one nut onto each stud. Fully tighten the nuts to 40-ft/lbs., only after all four are in place.
6. Repeat steps 1–5 on the other side.



FIG. 3



FIG. 4



FIG. 5



Installation Instructions Written by ExtremeTerrain Customer Anthony
Dombrowski 04/27/2016