

2007-2014 Side Step

Contents: (2) - Rock Sliders

1



Begin by locating the body mounts that run along the frame of the vehicle. You will use the (2) smaller threaded stud on either side of the body mount. There are (3) mounts on 4-doors, and (2) mounts on 2-doors

2



3



Slide the side step on top of the body mount and on to the threaded studs. Secure the side step using the factory hardware and torque to 40 ftlbs.