

## “Safari” Top Installation:

1.



- Lay top across roll cage and position near windshield.

2.



- Attach the front flat hooks to existing front windshield mounts, make sure the strap is behind the hook! **It's Important to do this first!**

3.



- Roll top to rear of the vehicle while keeping top centered on roll cage. Center bar magnet supports will align automatically.

4.



- Pull the center back straps to stretch out the top front to back. Check for alignment, tighten straps and stretch top to a tight fit.

5.



- Snap and adjust the memory buckles starting at the front and continue to the rear.

6.



- Tighten and adjust as necessary. Buckles are very strong and materials will stretch just don't overdo. To remove just reverse - it's faster the second time!

• Use and care instructions: For warranty purposes it is highly recommended that your “Safari Top” be rolled for storage and stored in a safe location. Clean only with water and a soft cloth. Defects in materials and workmanship are covered under warranty, however we cannot be responsible for misuse, improper storage or trail damage