

Jeep JK 4 Door 2 Piece Installation Instructions

PLEASE READ CAREFULLY BEFORE STARTING INSTALLATION

To safely lift and install this hardtop, you will need the assistance of at least one other person.

Follow the instructions and perform the steps in the sequence given. Short cuts to the directions may result in an unsatisfactory installation.

WARNING!

The top on this vehicle is designed only for additional protection against the elements.

Do not rely on the top to contain occupants within the vehicle or to protect against intrusion of foreign objects, nor injury during an accident.

Make sure all brackets and screws are tight. Periodically check for tightness and retighten when necessary.

WEAR SEAT BELTS AT ALL TIMES

Parts included in the installation kit.

6 each	Bolt 5/16-18 x 1 1/4
6 each	Nut 5/16-18
6 each	Washer 3/8 USS Flat
2 each	Mid Body Hex Bolt M8 x 30
2 each	5/16" USS Flat Washers

Rev. 11/10/19



1. Remove side windows. (Left & right)



2. Disengage front clips and remove 2 screws holding the retainer loop. Remove loop. Both sides.



3. Disengage soft top in rear corner. (Left & right)



4. Disengage soft top rear bar from retainers. (Left & right)



5. Remove retainers. (Left & right)



6. Disengage soft top from the top rail retainers. (Left & right)



7. Unscrew the 3 attach knobs along each side. (Left & right)



8. Remove soft top rail. (Left & right)



9. Disengage soft top mechanism



10. Disengage soft top mechanism at diagonal roll bar mount and remove mount. Remove soft top from vehicle.



11. Do Not Remove Front End Seals.



12. Do Not Remove Rear End Seals.



13. Using 2 people, place the rear section on the Jeep.



14. Install the side rail bolts using the supplied washers and nuts. Do not tighten.



15. Install the mid body bolt and washer. On the front of the rear section.



16. Tighten the flange bolts and mid body bolts. Now check to make sure the doors open and close properly. If not loosen the top and and adjust it.



18. Now install the front section. Make sure it's lined up even in the front. The distance from the top to the upper door should be the same. Now push up on the windshield seal (red arrows) and close the front cam locks. Then close remaining cam locks.



19. Now connect the cam locks in the front. Then connect the middle cam lock in the back. The connect the side cam locks.

Made with PRIDE in the USA.
ENJOY.

ATTN: STATE OF CALIFORNIA CONSUMERS



WARNING: CANCER AND REPRODUCTIVE HARM
WWW.P65WARNINGS.CA.GOV