

Installation Instructions for Rough Country Steering Stabilizer

Installation Time: 45 Minutes

Tools Required:

- ✓ ½ Socket/Wrench
- ✓ ¾ Socket/Wrench
- ✓ Hydraulic Jack

Installation Instructions:

1. Remove the factory/aftermarket steering stabilizer



2. Install Rough Country Relocation Bracket by removing current stabilizer bracket bolt.



3. Install Rough Country Steering Stabilizer on axle mount and newly installed relocation bracket and tighten completely. Next, using Hydraulic Jack, lift front end of Jeep and turn driver side wheel inward.



4. Loosen track bar mount and rotate 90 degrees.



5. Complete install by installing opposite end of the Rough Country Steering Stabilizer and tighten completely.

