



**PLEASE BE SURE TO
TIGHTEN THE SCREWS IN
THE MIRROR HEAD
BEFORE USE!!!**

THANK YOU!!!!!!

3 of 5

		3
		... 001 001 001 001
10000001	кредитование на долгосрочные	
10000002	кредитование на среднесрочные	
10000003	кредитование на краткосрочные (до 6 мес)	
10000004	кредитование на срок до 6 мес	
10000005	кредитование на срок до 6 мес	
10000006	кредитование на срок до 6 мес	
10000007	кредитование на срок до 6 мес	
10000008	кредитование на срок до 6 мес	
10000009	кредитование на срок до 6 мес	
10000010	кредитование на срок до 6 мес	
10000011	кредитование на срок до 6 мес	
10000012	кредитование на срок до 6 мес	
10000013	кредитование на срок до 6 мес	
10000014	кредитование на срок до 6 мес	
10000015	кредитование на срок до 6 мес	
10000016	кредитование на срок до 6 мес	
10000017	кредитование на срок до 6 мес	
10000018	кредитование на срок до 6 мес	
10000019	кредитование на срок до 6 мес	
10000020	кредитование на срок до 6 мес	

10000021	кредитование на срок до 6 мес	
10000022	кредитование на срок до 6 мес	
10000023	кредитование на срок до 6 мес	
10000024	кредитование на срок до 6 мес	
10000025	кредитование на срок до 6 мес	
10000026	кредитование на срок до 6 мес	
10000027	кредитование на срок до 6 мес	
10000028	кредитование на срок до 6 мес	
10000029	кредитование на срок до 6 мес	
10000030	кредитование на срок до 6 мес	



Order Fulfillment Request

Date: August 12, 2016
Order #: 08122016-295023

Order From:	Ship to:	Deliver to: (check one)
Matthew Harvey Kikbax Off Road 512 Wichita Trail McKinney, TX 75071 matthew4904@gmail.com (903) 453-4904	[Name] AmericanMuscle.com [Company] 1 Lee Blvd [Address 1] Unit 4 [Address 2] Malvern, PA 19355 [City, State & ZIP] [Phone]	Home Address _____ Business Address <u> x </u> _____

Special Instructions: Parts: J105121/KJ58001, J105123/KT590011, J105125/KY58001

Item #	Description	Qty Ordered
KJ58001	Kikbax JK Foot Pegs w/ mirrors	1
KT590011	Kikbax TJ Foot Pegs w/ mirrors	1
KY58001	Kikbax YJ Foot Pegs w/ mirrors	1
KM57001	5" diameter mirror	
KJ58003	Kikbax JK Rear Foot Pegs	
KJ58002	Kikbax JK Front Foot Pegs Only	
KDB1001	Kikbax Door Hanging Bracket (2 per pkg)	
KBDSM-01	Kikbax Driver Side Merchandiser	
KBPSM-01	Kikbax Passenger Side Merchandiser	
		Total Qty Ordered
		3

2 of 3

Kikbax Installation instructions

Installation of Kikbax YJ (1987-1995)

Step 1: Take off your doors!

Step 2: Prepare your door strap hook. Make sure the door strap hook is in the upright position (factory position), and not bent towards the door jamb. Some adjustments to the door strap hook may be required. There are two solutions if the hook is in fact bent: Buy a new door strap hook, or the Jeep Method: Use the circular side of a 1/2" wrench to bend the door strap hook back into the original upright position.

Step 3: Position Kikbax YJ over the two door hinges and the door strap hook.

Step 4: As you guide the top hinge in, the bottom hinge and door strap hook should line up as well.

Step 5: Once both hinges and door strap hook are lined up, push Kikbax YJ down to lock into the hinges and door strap hook. Kick back and relax!

Installation of Kikbax TJ (1997-2006)

Step 1: Take off your doors!

Step 2: Prepare your door strap hook. Make sure the door strap hook is in the upright position (factory position), and not bent towards the door jamb. Some adjustments to the door strap hook may be required. There are two solutions if the hook is in fact bent: Buy a new door strap hook, or the Jeep Method: Use the circular side of a 1/2" wrench to bend the door strap hook back into the original upright position.

Step 3: Guide Kikbax TJ into the top door hinge. Once the top hinge is in, Kikbax TJ should line up with the bottom hinge. The same way you would line up the hinges of a door.

Step 4: Now swing Kikbax TJ in toward the door jamb, making sure Kikbax TJ align with the dome light button. Lifting them slightly, slide Kikbax TJ up and over the door strap hook then push them down safely around the door strap hook.

Step 5: At this point your Kikbax TJ should be flush with the door hinges and locked in place. Kick back and relax!

Installation of Kikbax JK/JKU (2007-Present)

Step 1: Take off your (front) doors!

Step 2: Guide Kikbax JK into the top door hinge. Once the top hinge is in, Kikbax JK should line up with the bottom hinge. The same way you would line up the hinges of a door.

Step 3: Swing Kikbax JK towards the door jamb until they meet the door strap hook.

Step 4: Lift Kikbax JK up and over the door strap hook.

Step 5: Push down on Kikbax JK foot peg, locking Kikbax JK firmly in place behind the door strap hook. At this point your Kikbax JK should be flush with the door hinges and locked in place. Kick back and relax!

**Kikbax foot pegs are intended for off-road use while vehicle is not in motion. Chenery Jeep LLC does not recommend any part of your body outside of your vehicle while in motion.*

@kikbaxoffroad

facebook.com/kikbaxoffroad

Kikbax Offroad

www.KikbaxOffroad.com

