

Kikbax Installation instructions

Installation of Kikbax YJ (1987-1995)

Step 1: Take off your doors!

Step 2: Prepare your door strap hook. Make sure the door strap hook is in the upright position (factory position), and not bent towards the door jamb. Some adjustments to the door strap hook may be required. There are two solutions if the hook is in fact bent: Buy a new door strap hook, or the Jeeper Method: Use the circular side of a 1/2" wrench to bend the door strap hook back into the original upright position.

Step 3: Position Kikbax YJ over the two door hinges and the door strap hook.

Step 4: As you guide the top hinge in, the bottom hinge and door strap hook should line up as well.

Step 5: Once both hinges and door strap hook are lined up, push Kikbax YJ down to lock into the hinges and door strap hook. Kick back and relax!

Installation of Kikbax TJ (1997-2006)

Step 1: Take off your doors!

Step 2: Prepare your door strap hook. Make sure the door strap hook is in the upright position (factory position), and not bent towards the door jamb. Some adjustments to the door strap hook may be required. There are two solutions if the hook is in fact bent: Buy a new door strap hook, or the Jeeper Method: Use the circular side of a 1/2" wrench to bend the door strap hook back into the original upright position.

Step 3: Guide Kikbax TJ into the top door hinge. Once the top hinge is in, Kikbax TJ should line up with the bottom hinge. The same way you would line up the hinges of a door.

Step 4: Now swing Kikbax TJ in toward the door jamb, making sure Kikbax TJ align with the dome light button. Lifting them slightly, slide Kikbax TJ up and over the door strap hook then push them down safely around the door strap hook.

Step 5: At this point your Kikbax TJ should be flush with the door hinges and locked in place. Kick back and relax!

Installation of Kikbax JK/JKU (2007-Present)

Step 1: Take off your (front) doors!

Step 2: Guide Kikbax JK into the top door hinge. Once the top hinge is in, Kikbax JK should line up with the bottom hinge. The same way you would line up the hinges of a door.

Step 3: Swing Kikbax JK towards the door jamb until they meet the door strap hook.

Step 4: Lift Kikbax JK up and over the door strap hook.

Step 5: Push down on Kikbax JK foot peg, locking Kikbax JK firmly in place behind the door strap hook. At this point your Kikbax JK should be flush with the door hinges and locked in place. Kick back and relax!

**Kikbax foot pegs are intended for off-road use while vehicle is not in motion. Chenery Jeeper LLC does not recommend any part of your body outside of your vehicle while in motion.*

@kikbaxoffroad

facebook.com/kikbaxoffroad

Kikbax Offroad

www.KikbaxOffroad.com



**PLEASE BE SURE TO
TIGHTEN THE SCREWS IN
THE MIRROR HEAD
BEFORE USE!!!**

THANK YOU!!!!!!



Order Fulfillment Request

Date: August 12, 2016
Order #: 08122016-295023

Order From:**Ship to:**

Matthew Harvey
Kikbax Off Road
512 Wichita Trail
McKinney, TX 75071
matthew4904@gmail.com
(903) 453-4904

[Name]
[Company]
[Address 1]
[Address 2]
[City, State & ZIP]
[Phone]

AmericanMuscle.com
1 Lee Blvd
Unit 4
Malvern, PA 19355

Deliver to: (check one)

Home Address _____

Business Address ___x___

Special Instructions: Parts: J105121/KJ58001, J105123/KT590011, J105125/KY58001

Item #	Description	Qty Ordered
KJ58001	Kikbax JK Foot Pegs w/ mirrors	1
KT590011	Kikbax TJ Foot Pegs w/ mirrors	1
KY58001	Kikbax YJ Foot Pegs w/ mirrors	1
KM57001	5" diameter mirror	
KJ58003	Kikbax JK Rear Foot Pegs	
KJ58002	Kikbax JK Front Foot Pegs Only	
KDB1001	Kikbax Door Hanging Bracket (2 per pkg)	
KBDSM-01	Kikbax Driver Side Merchandiser	
KBPSM-01	Kikbax Passenger Side Merchandiser	

Total Qty Ordered
3

3 of 3

3 of 3

		Product Name
1001		
1002		
1003		
1004		
1005		
1006		
1007		
1008		
1009		
1010		
1011		
1012		
1013		
1014		
1015		
1016		
1017		
1018		
1019		
1020		
1021		
1022		
1023		
1024		
1025		
1026		
1027		
1028		
1029		
1030		
1031		
1032		
1033		
1034		
1035		
1036		
1037		
1038		
1039		
1040		
1041		
1042		
1043		
1044		
1045		
1046		
1047		
1048		
1049		
1050		
1051		
1052		
1053		
1054		
1055		
1056		
1057		
1058		
1059		
1060		
1061		
1062		
1063		
1064		
1065		
1066		
1067		
1068		
1069		
1070		
1071		
1072		
1073		
1074		
1075		
1076		
1077		
1078		
1079		
1080		
1081		
1082		
1083		
1084		
1085		
1086		
1087		
1088		
1089		
1090		
1091		
1092		
1093		
1094		
1095		
1096		
1097		
1098		
1099		
1100		
1101		
1102		
1103		
1104		
1105		
1106		
1107		
1108		
1109		
1110		
1111		
1112		
1113		
1114		
1115		
1116		
1117		
1118		
1119		
1120		
1121		
1122		
1123		
1124		
1125		
1126		
1127		
1128		
1129		
1130		
1131		
1132		
1133		
1134		
1135		
1136		
1137		
1138		
1139		
1140		
1141		
1142		
1143		
1144		
1145		
1146		
1147		
1148		
1149		
1150		
1151		
1152		
1153		
1154		
1155		
1156		
1157		
1158		
1159		
1160		
1161		
1162		
1163		
1164		
1165		
1166		
1167		
1168		
1169		
1170		
1171		
1172		
1173		
1174		
1175		
1176		
1177		
1178		
1179		
1180		
1181		
1182		
1183		
1184		
1185		
1186		
1187		
1188		
1189		
1190		
1191		
1192		
1193		
1194		
1195		
1196		
1197		
1198		
1199		
1200		

1001	1002	1003	1004
1005	1006	1007	1008
1009	1010	1011	1012
1013	1014	1015	1016
1017	1018	1019	1020
1021	1022	1023	1024
1025	1026	1027	1028
1029	1030	1031	1032
1033	1034	1035	1036
1037	1038	1039	1040