



## 07-17 2.5" Stainless Steel Exhaust Spacer

### Contents:

- (1) Driver's Side Spacer (Short)
- (1) Passenger Side Spacer (Long)
- (2) M8 x 80mm Bolts (Short)
- (2) M8 x 90mm Bolts (Long)
- (4) M8 Washers

1. On a level surface, with the engine cold, raise and support the vehicle on jack stands.
2. Loosen the Y-pipe to mid-pipe exhaust clamp.
3. Grind the locating tab off the y-pipe to allow the y-pipe to slide further onto the mid-pipe.
4. Remove the factory bolts holding the y-pipe to the headers.
5. Remove the rubber exhaust hangers from the y-pipe and mid-pipe if necessary.
6. Install the short exhaust spacer on the driver's side and the long spacer on the passenger side between the y-pipe and header.
7. Reconnect the y-pipe to the headers using the short bolts on the driver side and the long bolts on the passenger side.
8. Ensure adequate exhaust clearance before tightening to the y-pipe to mid-pipe exhaust clamp. Loosen bolts and exhaust clamp to adjust as needed.