

Jeep Wrangler JK (2007-2015)

HD Tire Carrier for OEM Tire Mount

Contents:

- (2) Hinge Mounts
- (1) Tire Carrier Bracket
- (1) Foam
- (2) Hinge Pins w/ c-clips
- (1) Thin Spacer
- (1) Thick Spacer
- (1) Hardware Kit

Tools Required:


- Socket Set
- Allen Sockets
- T-50 Torx
- Panel Removal Tool




Begin by removing the spare tire.



Open the tailgate to access the 3rd brake light connector. Remove the vent cover with a panel removal tool. Unclip the brake light wiring harness. Close the tailgate. Do not install the vent cover.



Remove the (8) 13mm bolts holding the factory tire carrier in place. Remove the 3rd brake light wiring grommet to remove the plug from the vehicle.




Using a panel removal tool, remove the factory air vent.



Next, apply painters tape to the vehicle so that you can line up the tailgate correctly if need. Mark the tailgate in several locations. Use a straight edge to mark the tape as a visual reference. Use a razor blade to cut the tape in half at the seam.




Shim the bottom of the tailgate to prevent it from sagging when the hinge bolts are removed.



Remove the plastic hinge covers followed by (2) 13mm bolts securing the hinge each hinge to the tailgate.



With the hinges unbolted from the tailgate, open the hinge to access the (3) T-50 Torx bit bolts.



Attach the supplied hinge mounts using the factory T-50 Torx bolts. Tighten the bolts down is several passes, they will self-center.



Install the foam cover for the air vent hole. Remove the double sided tape backing on all (4) corners. Install the foam to the tire carrier bracket.



Install the tire carrier bracket to the hinges using the supplied hinge pins. Once installed secure the hinge pins using the provided c-clips. **Note: A rubber mallet may be needed to seat the hinge pins.



12

Place the thin spacer behind the upper tire carrier bracket mount, and the thick bracket behind the lower tire carrier bracket mount.



13

Use the factory hinge bolts to secure the tire carrier bracket to the tailgate. Ensure the reference marks made earlier still line up prior to tightening the tire carrier bracket.



14

Install the factory tire carrier on top of the Barricade tire carrier bracket using the factory hardware.



15

Route the brake light wiring back into the car. Plug the connection in and re-install the vent cover.