



Remove the (2) factory 13mm tire carrier bolts. Reinstall the bolts through the CB Antenna mount.