

Bestop Windjammer

Installation Time: 30 Minutes

Tools Required:



- ✓ 3/8" Ratchet
- ✓ T40 Torx bit socket

Installation Instructions:

1. If your Jeep comes equipped with a factory soft top, first remove the soft top from the pivoting brackets, next remove each pivoting bracket from the B pillars with the T40 torx bit.



2. Position the WindJammer loosely into position using the highlighted fasteners.



3. Once all the straps have been started. Begin to tighten them into position.



4. Once all the straps have been pulled tight, it concludes the installation of the WindJammer.

Before

After



Installation Instructions Written by ExtremeTerrain Customer Louis Orellana 06/21/2016