

Install Guide for Rugged Ridge Black Powder Coated Light Bar

Tool List:

- T-40 torx socket or driver
- 6mm allen key
- Phillips screwdriver



Left upright- Passenger side

Right upright- Driver side

Cross pieces-Over windshield

6mm bolts- mount uprights to windshield

Phillips screws- mount crossbar to uprights

While installing do not over tighten bolts to allow for some movement while installing other pieces

Before Installation Picture



Remove the top two T-40 screws on passenger side of windshield



Place passenger upright over hole and align. Insert two of the supplied 6mm bolts and washers. Hand tighten.



Repeat for drivers side



Mount crossbar onto uprights and put Philips screw with washer into hole. Hand tighten



Go back and tighten down all bolts and screws until tight.

Finished picture of installation of Rugger Ridge light bar



Guide made by Austin Hodge, February 17, 2017