Rugged Ridge Jeep Window Storage Bag Installation Guide

Installation Time: 15 minutes

Tools Required:

✓ None

When you unpack the box, you should have the following:

- 1. [1] Soft felt-like protective window wrap
- 2. [1] Nylon draw string bag



Installation Instructions:

1. Place protective window wrap on flat surface and unroll it.



2. You will notice there are four layers. I color-coded these layers to make them easier to distinguish from one another for purposes of this guide.

Red = outer layer (place driver side window on this layer)

Yellow = first layer (this covers driver side window and place passenger side window on this layer)

Blue = second layer (this covers the passenger side window and place the rear window on this layer

Green = third layer (this covers the rear window)



3. Open all three layers so you have the outer layer on one side (the layer with the Velcro straps attached to the top) and the other three layers on the other side.



4. Place the driver's side quarter window on the left side of the outer layer. Place it so the "outside" of the window is facing down on the outer layer. The plastic door rail retainer should be closest to the top where the Velcro straps are.



5. Place the first layer over the driver side window and place the passenger side window face down on the right side of the first layer with the door retainer closest to the top where the Velcro straps are (in the picture, I left the one corner unfolded to show the driver and passenger windows next to each other).





6. Place the second layer over the passenger side window and place the rear window face down on the bottom of the second layer with the tailgate bar closest to the bottom where the bottom (please note, you do not need to remove the tailgate bar).



7. Once you have all three windows placed in the protective layers, it should look like this.



8. Place the third layer over the rear window.



9. Starting from the bottom, carefully roll up the protective layers towards the Velcro straps at the top.



10. Secure the Velcro straps around the cover so it stays rolled up.



11. Pull the drawstring on one side of the nylon bag. Then slide the other side of the nylon bag over the rolled up protective cover.



12. Pull the drawstrings so both sides of the nylon bag are closed.



13. Place the closed nylon bag across the back cargo area of the Jeep (if your soft top is down, you can place the nylon bag on top of the folded soft top).



14. Secure the nylon bag to the Jeep by fastening and tightening the nylon buckle straps to the roll bars on both sides of the Jeep.



Installation Instructions Written by ExtremeTerrain Customer Lori N. on 4/30/2017