

Bushwacker Cowl Vent Air Scoop Textured Black (98-17 Wrangler TJ & JK) Installation Guide

Installation Time: 5 Minutes

Tools Required:

- ✓ Tape

Installation Instructions:

1. Inspect the intake area for any large debris



2. Wipe down the air intake area with the included alcohol wipe



3. Place the vent scoop on the hood where you wish it to stay



4. Mark the corners of this area with tape



5. Peel back this amount of the tape



6. Place the scoop over the vent, making sure to match up the edges with the pieces of tape



7. Once in place, pull the tape out from in-between the body and cover



8. Push down, WITH TWO HANDS, on the vent. Also make sure to push on the edges so the tape adheres to the body



9. Remove the tape used to align the vent scoop



10. Finished

