



Rock Sliders (18+ JL 4-Door)

Contents:

- (1) Driver Side Rocker Step
- (1) Passenger Side Rocker Step
- (12) 3mm Spacers

TOOLS REQUIRED:

- 10mm, 13mm, and 18mm Sockets
- Ratchet
- Clean Towel
- Cleaning Solution



STEP 1 //

Begin by locating the (3) pinch weld mounting locations under the vehicle.



STEP 2 //

From under the vehicle, remove all (6) 10mm nuts holding the factory side step to the pinch welds of the vehicle.



STEP 3 //

From under the vehicle, locate and remove each of the 13mm body mount bracket bolts. **Note factory side step will now be loose.



STEP 4 //

Carefully pull the side step away from the vehicle and downward to remove from the vehicle. Take this time to clean the pinch welds, and body mounts from any road debris.



STEP 5 //

From under the vehicle, locate and remove the (3) 18mm body mount bolts. **Note, these bolts will be reused.



STEP 6 //

Install the rocker slider to the vehicle using the factory (3) 18mm bolts from Step 5. **Note if spacing is desired or with use of Rubi Rails, use the (12) 3mm spacers. Mount in between the rock sliders and the body of the vehicle. Secure with the factory (3) 18mm bolts from Step 5.