



**Installation Instructions**  
Windshield Header (Part # J126534)  
1997-2006 Jeep Wrangler

**Note:** Read instructions entirely before attempting to install this product.

**Step 1:** Remove the two bolts holding the clamps onto the channel, set bolts and clamps to the side temporarily.

**Step 2:** Place the windshield channel on top of your windshield frame. (Fig A)

**Step 3:** Place previously removed clamps into the slots on the inner top part of your windshield frame. Loosely start the bolts into the brackets. (Fig B)



(Fig A)



(Fig B)



(Fig C)

**Step 4:** While pushing the channel down and forward begin tightening the bolts going back and forth between them. (Do not tighten one side completely before the other) Installation is now complete.(Fig C) Make sure channel is secure on windshield frame.