

AXIAL

Installation Instructions for 2007 - 2018 JK Tri-Bar LED Fog Lights

Contents:

- (2) Fog Lights
- (2) Fog Light Connectors

Tools Required:

- Ratchet
- 8mm Socket
- Wire Crimping Tool



Step 1\\

Access the connectors on the rear of the fog lights from the wheel well, and remove. **Note: Light connector will be different between 07-09 and 10-18.



Step 2\\

Locate the (4) factory screws, and remove. **Note: Factory hardware will be reused.



Step 3\\

Install the new LED fog lights using the factory hardware.



Step 4\\

Plug the supplied wiring connector harnesses into each factory fog light connector and then connect to the new fog lights. Installation is now complete.