

97-06 TJ Wrangler Light Bar

Contents:

1. Light Bar (1)



1. TJ Light Bar can be installed with or without factory tow hooks. If factory tow hooks are present, they must be removed before the installation of the Light Bar. NOTE: Installation requires the use of factory tow hook mounting hardware. If you do not have factory tow hook mounting hardware you will need to source (4) 1/2-13 x 2.5" bolts to use for installation.

2. After removing factory tow hooks, place the Light Bar on the bumper with the logo facing forward. Line up the slots in the Light Bar mounting plates with the bumper mounting holes. Tighten Light Bar into place using factory torx head bolts.



3. To use factory tow hooks with this light bar, place tow hooks on top of Light Bar mounting plates. Be sure to use the correct tow hook for each side of the vehicle. Tighten Light Bar into place using factory torx head bolts.



4. You are now ready to install off-road lights (not included). Before driving, be sure the Light Bar and lights are securely fastened to the vehicle.



Rugged Ridge Limited Warranty

Applies to Rugged Ridge Products by OMIX-ADA Inc.

Please find warranty card supplied with product for more information. Warranty card should be filled out and returned to address listed below.

OMIX-ADA Inc.

**460 Horizon Dr. Suite 400
Suwanee, Georgia 30024**