

- Flat Head Screw Driver
- Soft Pry Tool
- Adhesive Remover



Open and support the hood. Locate the factory weather stripping. Using a soft tool, pry the weatherstripping off the factory grille. Factory weatherstripping will not be reused. \*\*Note: If there is any remaining adhesive on the paint. A quality adhesive remover will need to be used to remove the remaining adhesive.



Thoroughly clean the grille cover with soap and water to remove any dirt, oil, grease, wax, etc. \*\* Recommended: Use isopropyl alcohol to wipe the painted surfaces that will make contact with the 3M tape. A clean surface is essential for proper adhesion of the 3M tape. Allow the grille surface time to thoroughly dry before continuing to Step 3.



Using a soft pry tool, remove the (2) plastic push clips, (1) on either side of the grille. These will be reused to attach the Brow. Test fit the Brow before removing the tape backing.



Once familiar with how the Brow fits, remove the (8) small pieces of tape and fold back only a corner of the strip that runs along the top edge. Hold the bottom of the Brow off the grille while you install the factory push clips, then pull off the folded back portion of the tape backing. Push the bottom of the Brow against the grille seating the (8) small pieces of tape to the vehicle. Apply firm even pressure to all taped surfaces to ensure proper adhesion.