

07-18 JK Grab Handles Install Guide

Contents:

- (2) Grab Handles
- (2) M8x1.25 70mm Hex Head Bolts
- (2) M8x1.25 100mm Hex Head Bolts
- (2) 40mm Spacers
- (2) 70mm Spacers

Tools Required:

- 13mm Socket
- 6mm Allen Key/Socket
- Ratchet



//Step 2.

Begin by loosely installing (1) M8x1.25 70mm bolt and 40mm spacer into the vehicle per side [B]. The spacer fits in between the grab handle and the A-Pillar panel.



//Step 4.

Once both bolts are threaded in, firmly tighten both bolts per side using a 6mm allen key/socket, installation is now complete [D].



// Step 1.

Remove the (2) 13mm bolts per side along the A-Pillar [A].



//Step 3.

Install the (1) M8x1.25 100mm bolt with the (1) 70mm spacer per side [C]. The spacer goes in between the grab handle and the A-Pillar panel.