

JK Rear Grab Handles Installation Guide

J132493

Contents:

- (2) Rear Grab Handles
- (4) M6x1.00 45mm Bolts

Tools Required:

- 10mm socket
- 5mm Allen key/socket



//Step 1:

Remove (2) 10mm bolts partially securing the speaker to the roll bar.



//Step 2:

While holding the grab handle up, use the supplied (2) M6x1.00 45mm bolts and tighten the grab handle to the roll bar using a 5mm allen key. Tighten the bolts evenly. Repeat procedure to opposite side.