

# Antenna Base

## 18+ Jeep Wrangler JL

### Contents:

(1) - Antenna Base

### Tools Required:

- Soap & Water
- Clean Towel
- Isopropyl Alcohol

2



Familiarize yourself with how the antenna base fits prior to peeling off the tape backing. Then remove the tape backing and apply firm even pressure to ensure proper adhesion.

1



Remove the factory antenna rod. Wash the factory antenna mount with soap and water. Allow the antenna mount time to dry. \*\*Recommended: Wipe the mount down with isopropyl alcohol to ensure the cleanest surface possible.

3



Reinstall the factory antenna rod. Installation is now complete.