

# 21" Trail Antenna

97-06 Jeep Wrangler TJ  
07-18 Jeep Wrangler JK  
18+ Jeep Wrangler JL

## Contents:

(1) - 21" Trail Antenna

## Tools Required

- Adjustable Wrench

1



Locate the factory antenna and antenna base.

2



Carefully twist the antenna counter-clockwise to remove. Remove the factory antenna.

3



Install the new antenna by twisting it clockwise. Installation is now complete.