JK Bullet Antenna Installation Guide

Contents:

- (1) Antenna
- (1) 13mm I.D. Spacer
- (2) 7.5mm I.D. Spacer
- (6) Threaded Antenna Fittings
- (1) Threaded Antenna Spacer



- Adjustable Wrench



//Step 2: Assemble the bullet antenna fitting. Using (2) 7.5mm spacers, install them on the threaded fitting first. Then, install (1) 13mm spacer onto the threaded fitting.



//Step 4:Thread antenna onto vehicle antenna base. Tighten until snug on vehicle. Once antenna is tight, installation is complete.



// Step 1:
Begin by removing your original antenna by using an adjustable wrench and turning the antenna counter clockwise.



//Step 3: Once all spacers are on the fitting, thread the fitting onto the antenna. Tighten until secure.