



STEERING STABILIZER

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Steering Stabilizer

TOOLS REQUIRED

- Jack
- Jack Stands
- Torque Wrench
- Metric Socket Set (15-22mm)
- Metric Wrenches/ Adjustable Wrench

SKU # J132856



STEP 1

Raise and support the vehicle using a Jack and Jack Stands. Locate and remove the (2) 18mm fasteners securing the steering stabilizer to the vehicle.



STEP 2

Install the new steering stabilizer in reverse order using the factory hardware. Torque both fasteners to 50 ft. lbs.